

STRETCH SLIPCOVER



- 4-Way Stretch fits a variety of chair styles
- Secure fit with sewn-in bottom elastic hem
- Machine washable
- Easy Care - Wrinkle Resistant

Before fitting product on furniture, we recommend washing dark colours before covering light coloured furniture.

94% Polyester / 6% Elastane

CARE INSTRUCTIONS
Machine wash separately
in cold water, gentle cycle.
Do not use bleach.
Tumble dry low.
Do not iron.

Distributed by Interfab Pty Ltd.
303-309 Abbots Rd, Dandenong South,
Melbourne, Australia. www.interfab.com.au

sure **fit**[®]
slipcovers + home solutions

1 SEATER SOFA
EBONY

How To Assemble:

Step 1



Drape slipcover over furniture using positioning labels. Start at either side and stretch over and down arms.

Step 2



Tuck and smooth excess fabric into crevices. Lift and wrap the elastic under back and sides of the seat, pushing down and under cushions.

Step 3



Continue to smooth out until even all around.

Fits most 1 seater sofas.
(sofa length from 81cm to 109cm)